



ThinkPad® T580/P52s

Setup Guide


Lenovo™

Unpack


Standard items



Optional accessories



Lenovo USB-C to DisplayPort Adapter *




Lenovo HDMI to VGA Adapter *


* Available on some models

E-manual



Initial setup





- | | |
|---|---|
| 1. Infrared camera * | 2. Conventional camera (available on models with the infrared camera) |
| 3. Microphones | 4. Conventional camera with camera shutter * |
| 5. Screen (multi-touch function available on some models) | 6. Power button |
| 7. NumLock key with indicator | 8. NFC mark * |
| 9. Fingerprint reader * | 10. TrackPoint® buttons |
| 11. Trackpad | 12. CapsLock key with indicator |
| 13. Esc key with the Fn Lock indicator | 14. F1 key with the speaker mute indicator |
| 15. F4 key with the microphone mute indicator | 16. TrackPoint pointing stick |

* Available on some models

❗ Read the statement on USB transfer rate in the *User Guide*. Refer to the *Safety and Warranty Guide* for accessing the *User Guide*.

Compliance with the EU Radio Equipment Directive

The following applies to models with a radio device.

Hereby, Lenovo (Singapore) Pte. Ltd., declares that the radio equipment type ThinkPad T580 and P52s is in compliance with Directive 2014/53/EU.

For further information about EU regulatory compliance, refer to the *Safety and Warranty Guide* that comes with your computer.

Second Edition (August 2019)
© Copyright Lenovo 2018,2019.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Reduce | Reuse | Recycle

