

# Red Hat Enterprise Linux 9 Installation

Lenovo ThinkStation PX, P8, P7, P5



# Table of Contents

Overview .....	3
Section 1 – BIOS Setup .....	4
Section 2 – RHEL 9 Installation.....	8
Section 3 – Install Device Drivers.....	17
Section 4 – Install Nvidia Proprietary Drivers .....	18
Revision History .....	22



---

## Overview

The purpose of this document is to provide high-level guidance for users to adequately install a Red Hat Enterprise Linux 9 operating system on the ThinkStation PX, P8, P7, and P5 platforms.


---

## Section 1 – BIOS Setup


Prior to installing any operating system, it is important to make sure BIOS recognizes the storage devices appropriately.

Here are some key items to look for within BIOS setup.


At the Lenovo splash screen, press the function key F1 to enter BIOS setup.




Select 'System Summary' from the main BIOS setup page.




Scroll down through the list until you see the type of drive(s) you are intending to use. Note, drives may not show up here if drives are part of a RAID array.



Select 'Devices' -> 'Storage Setup' to make sure the drive is enabled.



For PCIe drives, select 'Devices' -> 'PCI Express Setup' and select the slot for where the drive is physically installed. In this example, the M.2 drive is installed in Slot 1.



Make sure the drive is linking properly.



The screenshot shows the BIOS configuration for M.2 Slot1. The 'Link Speed' dropdown is set to 'Auto'. A red box highlights the following status information:

PCIe Port Link Status	Linked as x4
PCIe Port Link Max	Max Width x4
PCIe Port Link Speed	Gen 4 (16.0 GT/s)

Navigation keys at the bottom: F1 Help, ESC Exit, Up/Down Select Item, Left/Right Select Menu, +/- Change Values, Enter Select > Sub-Menu, F9 Setup Defaults, F10 Save and Exit. Version 2.21.0052. Copyright (C) 2022 AMI.

Here's an example of BIOS not recognizing a PCIe drive.

The screenshot shows the BIOS configuration for M.2 Slot2. The 'Link Speed' dropdown is set to 'Auto'. A red box highlights the following status information:


PCIe Port Link Status	Link Did Not Train
PCIe Port Link Max	Max Width x4
PCIe Port Link Speed	Link Did Not Train

Navigation keys at the bottom: F1 Help, ESC Exit, Up/Down Select Item, Left/Right Select Menu, +/- Change Values, Enter Select > Sub-Menu, F9 Setup Defaults, F10 Save and Exit. Version 2.21.0052. Copyright (C) 2022 AMI.

## Section 2 – RHEL 9 Installation


Here are some step-by-step instructions on how to get a Red Hat Enterprise Linux 9 operating system installed on the ThinkStation PX, P8, P7, and P5 systems.

1. Obtain a copy of the RHEL 9 installation media. It is recommended to use Fedora Media Writer to make an installation USB with the appropriate RHEL 9 iso media.
2. Insert the USB memory key into one of the USB ports on the system and power on the system.
3. At the Lenovo splash screen, press the function F12 key to enter the BIOS startup menu and select the USB installation media from the list.







4. Select the 'Install Red Hat Enterprise Linux 9.0' option from the GRUB boot menu and press 'Enter'.




5. The Red Hat Enterprise Linux Welcome screen should appear. Select the appropriate language from the list of options and 'Continue'.




- Adjust the 'Keyboard', 'Language Support', and 'Time & Date' accordingly by selecting each one. Or, leave the default settings.



- Select the 'Software Selection' and choose the type of software to install.



8. Select the type of 'Base Environment' as well as each additional software to install.  
*In this example, 'Workstation' was selected for the 'Base Environment' and all additional software tools were selected.*




**Base Environment**

- Server with GUI  
An integrated, easy-to-manage server with a graphical interface.
- Server  
An integrated, easy-to-manage server.
- Minimal Install  
Basic functionality.
- Workstation**  
Workstation is a user-friendly desktop system for laptops and PCs.
- Custom Operating System  
Basic building block for a custom RHEL system.
- Virtualization Host  
Minimal virtualization host.


**Additional software for Selected Environment**

- Backup Client**  
Client tools for connecting to a backup server and doing backups.
- GNOME Applications**  
A set of commonly used GNOME Applications.
- Headless Management**  
Tools for managing the system without an attached graphical console.
- Internet Applications**  
Email, chat, and video conferencing software.
- Office Suite and Productivity**  
A full-purpose office suite, and other productivity tools.
- Remote Desktop Clients**
- Smart Card Support**  
Support for using smart card authentication.
- Legacy UNIX Compatibility**  
Compatibility programs for migration from or working with legacy UNIX environments.
- Console Internet Tools**  
Console internet access tools, often used by administrators.
- Container Management**  
Tools for managing Linux containers
- Development Tools**  
A basic development environment.
- .NET Development**  
Tools to develop and/or run .NET applications
- Graphical Administration Tools**  
Graphical system administration tools for managing many aspects of a system.
- Network Servers**  
These packages include network-based servers such as DHCP, Kerberos and NIS.
- RPM Development Tools**  
Tools used for building RPMs, such as rpmbuild.
- Scientific Support**  
Tools for mathematical and scientific computations, and parallel computing.
- Security Tools**  
Security tools for integrity and trust verification.
- System Tools**  
This group is a collection of various tools for the system, such as the client for connecting to SMB shares and tools to monitor network traffic.


9. Select 'Installation Destination'.




10. Select the device on where to install the operating system.




11. Select 'Root Password'.




12. Enter a root password in both boxes below and select 'Done' in the upper left.




13. Select 'User Creation'.




14. Fill in the appropriate boxes below and select 'Done' in the upper left.




15. Select 'Begin Installation' to start the installation.



16. Once the installation completes, select 'Reboot System' at the bottom right.



17. Select the user icon and log in using the credentials created above.



Lenovo

18. Red Hat Enterprise Linux 9 Desktop screen.





---

## Section 3 – Install Device Drivers

Most of the standard building blocks used in the ThinkStation PX, P8, P7, and P5 platforms are native to the Red Hat Enterprise Linux 9 base kernel. It may be worth installing a proprietary graphics driver to get optimal performance from the graphics card. The next couple of sections provide some step-by-step instructions on how to install a proprietary Nvidia graphics driver in Red Hat Enterprise Linux.

Note, registering the system to the Red Hat subscription will allow for easy Linux updates. Here is a quick step to easily register and subscribe to the Red Hat subscription repositories.

```
# subscription-manager register  
# subscription-manager auto-attach
```

---

## Section 4 – Install Nvidia Proprietary Drivers

Here are some step-by-step instructions on how to install Nvidia proprietary drivers.

1. Download the appropriate Nvidia graphics driver.
2. Blacklist the Linux Nouveau driver.

```
# nano /etc/modprobe.d/blacklist.conf
```

- Add the following line, 'blacklist nouveau', and save and exit the file.



```
GNU nano 5.6.1
blacklist nouveau_
```

3. Update the initramfs file and reboot the system.

```
# dracut --force
```

```
# reboot now
```



```
[root@localhost Desktop]# dracut --force
[root@localhost Desktop]#
```

- Once the system reboots to the Linux desktop screen, run the following command as superuser from a terminal window to exit X-windows.

```
# init 3
```

- Login as root (superuser).

```
Red Hat Enterprise Linux 9.0 (Plow)
Kernel 5.14.0-70.13.1.el9_0.x86_64 on an x86_64

Activate the web console with: systemctl enable --now cockpit.socket

localhost login: root
Password:
Last login: Thu Nov 3 06:35:43 on tty1
[root@localhost ~]# _
```

- Browse to the directory to where the Nvidia driver installation file is located and run the following command. *In this example, it is on the Linux desktop.*

```
# bash NVIDIA*
```

```
Red Hat Enterprise Linux 9.0 (Plow)
Kernel 5.14.0-70.13.1.el9_0.x86_64 on an x86_64

Activate the web console with: systemctl enable --now cockpit.socket


localhost login: root
Password:
Last login: Thu Nov 3 06:35:43 on tty1
[root@localhost ~]# cd /home/lenovo/Desktop/
[root@localhost Desktop]# ls
NVIDIA-Linux-x86_64-515.76.run
[root@localhost Desktop]# bash NVIDIA-Linux-x86_64-515.76.run _
```

- Note the driver should start to install.


```
NVIDIA Accelerated Graphics Driver for Linux-x86_64 (515.76)

Building kernel modules
100%
```


- 8. The driver will ask whether to install NVIDIA's 32-bit compatibility libraries. *In this example, 'yes' was selected.*




- 9. Select 'OK' on the following warning message.




- 10. The driver should continue to install.



11. Select 'Yes' to update the x-configuration file.




12. Select 'OK' to acknowledge that the x-configuration file has successfully been updated.



13. Run the following command to verify the Nvidia driver has been installed and loaded properly.

# nvidia-smi



---

# Revision History

Version	Date	Author	Changes/Updates
1.1	12/12/2023	A Panteleev	Added support for P8
1.0	4/19/2023	J Moebs	Initial launch release.